## **SPECIFICATIONS**

INPUT IMPEDANCE.....> 36kΩ OUTPUT IMPEDANCE.....< 26kΩ

SIGNAL TO NOISE RATIO

(all controls at MID position)......> 82dBV 'A' Weighted

BYPASS.....True Bypass

DIMENSIONS...4-25/32" x 3-3/4" x 1-3/4"

WEIGHT.....14oz.

CURRENT DRAW......3.1mA (9V DC)

POWER SUPPLY.....Standard 9V battery, Dunlop ECB-03 AC Adapter, Dunlop DC Brick, or CAE MC-403.

\*0dBV = 1Vrms

Features: heavy-duty footswitch with quiet relay-based true bypass, blue LED indicator, 5.5mm x 2.1mm power jack with AC protection, easy access non-detachable battery door, super-duty 0.09" aluminum anodized chassis, high grade components, great tone and cool name.

LIVE TO PLAY LIVE®

© 2012 DUNLOP MFG. INC



JIMDUNLOP.COM

DUNLOP MANUFACTURING, INC. P.O. BOX 846 BENICIA, CA 94510 U.S.A. TEL: 1-707-745-2722 FAX: 1-707-745-2658 WWW.JIMDUNLOP.COM





WAY HUGE

WHE-401


Swollen Pickle mkII instruction manual

## The most sought after and corpulent Way Huge pedal is back!

First constructed in 1997 as part of the original Way Huge line. this stompbox still has more fuzz than a moldy peach!

The Swollen Pickle Mkll surrenders super high-gain fuzz with copious amounts of smooth low-end to all who dare plug into it, With a twist of the SUSTAIN control, you're taken from mild crunch to Armageddon! The FILTER control retains its trademark insane range of heavily band-pass-filtered tones distinguished by remarkable girth and sizzle, and the LOUDNESS puts out enough volume to clobber any amp! Newly added features include a tone stack SCOOP control that elicits classic Swollen Pickle mid-scoop or flat mid-frequency sweep, and a CRUNCH knob to adjust the compression intensity of the fuzz. Finally, under the hood, the Swollen Pickle MkII has two internal mini controls: VOICE sets the intensity of the external SCOOP control from light to heavy mid cut, and CLIP varies between two sets of clipping diodes for smooth or opened fuzz sustain.

> SWOLLEN PICKLE INTERIOR DRAWING: 4 RUBBER FEET TO ADJUST THE INTERNAL TONE CONTROLS)



OPENED FUZZ SUSTAIN

VOICE - SETS THE INTENSITY OF THE EXTERNAL SCOOP CONTROL

